

## 4125 Keaton Series



### 4125-ALL Keaton Angled Left Arm Loveseat

W67 D35 H31

Seat H18 / Arm H26 / Inside Seat W52 D21

### 4125-BR Keaton Right Bumper

W68 D35 H31

Seat H18 / Inside Seat W58 D21

### 4125 Keaton Sectional Series Components

1/4" = 1' Scale



### 4125-S1 Keaton Mid-Length Sofa

W79 D35 H31

Inside Seat W67 D21



### 4125-S2 Keaton Sofa

W86 D35 H31


Inside Seat W74 D21



### 4125-B1 Keaton Short Sofa

W72 D35 H31

Inside Seat W60 D21



### 4125-C1 Keaton Chair

W38 D35 H31

Inside Seat W26 D21



### 4125-O1 Keaton Ottoman

W28 D22 H16.5



### 4125-SL Keaton Left Arm Sofa

W81 D35 H31


Inside Seat W75 D21



### 4125-SR Keaton Right Arm Sofa

W81 D35 H31


Inside Seat W75 D21



### 4125-LL Keaton Left Arm Loveseat

W56 D35 H31

Inside Seat W50 D21



### 4125-LR Keaton Right Arm Loveseat

W56 D35 H31

Inside Seat W50 D21



**4125-SL Keaton Left Arm Sofa**

W81 D35 H31

Seat H18 / Arm H26 / Inside Seat W75 D21

**4125-CR Keaton Right Arm Chaise**

W40 D63.5 H31

Seat H18 / Inside Seat W38 D52



**4125-DL Keaton Left Arm Corner Sofa**

W93 D35 H31


Inside Seat W78 D21



**4125-DR Keaton Right Arm Corner Sofa**

W93 D35 H31


Inside Seat W78 D21



**4125-CL Keaton Left Arm Chaise**

W40 D63.5 H31


Inside Seat W38 D52



**4125-CR Keaton Right Arm Chaise**

W40 D63.5 H31

Inside Seat W38 D52



**4125-ALL Keaton Angled Left Arm Loveseat**

W67 D35 H31

Inside Seat W52 D21



**4125-ALR Keaton Angled Right Arm Loveseat**

W67 D35 H31


Inside Seat W52 D21



**4125-BL Keaton Angled Left Bumper**

W68 D35 H31

Inside Seat W58 D21



**4125-BR Keaton Angled Right Bumper**

W68 D35 H31

Inside Seat W58 D21